








TENDA GAZEBO
POP-UP 3X3M
PG-001





ATENDIMENTO AO CONSUMIDOR:
(31) 2565-3365


GUIA DE MONTAGEM

		
A	B	C
1	8	4


	
D	E
1	1




3




4




5




6




7



8



9



10

